

Digital Canal Corporation

Solution Papers

Summary: *Trimming Fascia Ends*

The tips, solutions, and suggestions outlined in Digital Canal Solution Papers are suggested for use at your own risk. Document contents are subject to change without notice. Digital Canal Corporation is not responsible or liable for damage or events that may occur as a result of following suggestions from any Digital Canal Technical Support document. All other product names are trademarks of their respective holders.

Overview: The following procedures below will accurately take you through the necessary steps to trim fascia ends to be plumb.

1. Select File / Cad Menu. Select an end view. Right Click select Face View→Select the end view needed, Right click again and select align C-space to view, to align the cursor.
2. Select Zoom Area and zoom in tight on the fascia end.
3. Select Geometry / Solid Modeling / Clip / Objects. With the mouse pointer click the fascia board to trim.
4. You are prompted to mark the location of the y-coordinate. Use the E end jump command and select the point at which to trim the fascia.
5. You are prompted to select point to indicate direction of clipping. Move the cross hairs down and left click. The fascia is now trimmed.